

# Replacement Remote Instructions

Lose your remote? Replacements are available from our office. Here's how to pair your replacement with your EVO PRO:

1

Ensure there are working batteries in the remote.


2

Power on the EVO PRO set-top box by pressing the "recovery" button on the bottom of the device with a sharp pin.





3

Launch the EVO PRO remote setup screen by using a sharp pin to hold in the recovery button for 5 seconds.




4

Follow the prompts on the screen. Press and hold the Back  and Home  buttons simultaneously until the LED on the top of the remote blinks. Then place the remote on top of the set-top box.

5

Once the "success" stage is completed, you will be able to use the remote.

6

Navigate to the settings icon  in the top right of the screen, and select Device Preferences>Smart Control to complete the setup.

More Helpful Guides at

[SELCO.ShrewsburyMA.gov/streamguides](http://SELCO.ShrewsburyMA.gov/streamguides)

